



## Step-by-Step Configuration

To access and configure your notification settings within the EnergyTrak app, follow these steps:

1. Open the EnergyTrak app and from the main screen, tap the **hamburger menu** (three horizontal lines) in the top-left corner of the screen.



2. From the side menu that appears, select "**Notifications**".



3. In the top-right corner of the screen, tap the **gear icon**. This opens the **Notifications settings menu**. The Notifications settings menu allows you to select which events trigger a notification and how you'd like to receive it (Push/In-App or Email).

10:42

70



BRIGGS&STRATTON



## Notifications

Manage and review your notifications history

November 9

EVENT

11:35:53 AM

EVENT

11:27:34 AM

4. Expand the category for the device(s) you want to configure (e.g., Batteries or Generators) by tapping the down arrow next to the category name.

10:42

70



BRIGGS&STRATTON

## Notification settings

Select email and push notifications for all assigned sites

Batteries





Generators



Email notifications are sent to the email address registered with your EnergyTrak account. You will receive selected notifications in response to events from any EnergyTrak site listed on your main Sites screen.

CANCEL

SAVE

5. Select the specific events for which you want to receive an alert. Grayed-out icons indicate no delivery method has been selected for the event, while green-shaded icons indicate a delivery method has been selected.
  - Tapping the mobile phone icon  enables **Push** (in-app) **notifications** for that event.
  - Tapping the envelope icon  enables **Email notifications** for that event.

10:43

70



BRIGGS&STRATTON

## Notification settings

Select email and push notifications for all assigned sites

**Batteries**

---

**Generators**

---

**DEVICE** SELECT ALL

---

EnergyTrak Device Internal Battery Low

---

EnergyTrak Device Internal Battery Normal

---

EnergyTrak Device Power Connected

---

EnergyTrak Device Power Disconnected

CANCEL

SAVE

6. Once you have made all your selections, be sure to tap the “**SAVE**” button at the bottom of the screen.


10:55




BRIGGS&STRATTON

## Notification settings




Select email and push notifications for all assigned sites

**Batteries** 



---

**Generators** 



---

**DEVICE**  SELECT ALL  



---

EnergyTrak Device Internal Battery Low  



---

EnergyTrak Device Internal Battery Normal  

---

EnergyTrak Device Power Connected  

---

EnergyTrak Device Power Disconnected  

CANCEL

SAVE